


Lecture 15 - Discrete Phase Modeling

Applied Computational Fluid Dynamics


Instructor: André Bakker

Discrete phase modeling

- Particle tracking.
- Steady vs. unsteady.
- Coupled vs. uncoupled.
- Advantages and limitations.
- Time stepping.
- Discretization.




Particle trajectories in a cyclone



Particle trajectories in a spray dryer

Discrete phase model

- Trajectories of particles/droplets are computed in a Lagrangian frame.
 - Exchange (couple) heat, mass, and momentum with Eulerian frame gas phase.
- Discrete phase *volume* fraction should preferably be less than 10%.
 - Mass loading can be large (+100%).
 - No particle-particle interaction or break up.
- Turbulent dispersion modeled by:
 - Stochastic tracking.
 - Particle cloud model.
- Model particle separation, spray drying, liquid fuel or coal combustion, etc.



DPM theory

Trajectory is calculated by integrating the particle force balance equation:

$$\frac{du_i^p}{dt} = F_D(u_i - u_i^p) + g_i(\rho_p - \rho) / \rho_p + F_i / \rho_p$$

drag force is
a function of the
relative velocity

Gravity force

Additional forces:

Pressure gradient


Thermophoretic

Rotating reference frame

Brownian motion

Saffman lift

Other (user defined)



Coupling between phases


- One-way coupling:
 - Fluid phase influences particulate phase via drag and turbulence.
 - Particulate phase has no influence on the gas phase.
- Two-way coupling:
 - Fluid phase influences particulate phase via drag and turbulence.
 - Particulate phase influences fluid phase via source terms of mass, momentum, and energy.
 - Examples include:
 - Inert particle heating and cooling.
 - Droplet evaporation.
 - Droplet boiling.
 - Devolatilization.
 - Surface combustion.

Particle types

- Particle types are inert, droplet and combusting particle.


Particle Type	Description
Inert	inert/heating or cooling
Droplet (oil)	heating/evaporation/boiling
Combusting (coal)	heating; evolution of volatiles/swelling; heterogeneous surface reaction

Heat and mass transfer to a droplet



Particle-wall interaction


- Particle boundary conditions at walls, inlets, and outlets:



- For particle reflection, a restitution coefficient e is specified:

$$\text{Normal component: } e_n = \frac{v_{2,n}}{v_{1,n}}$$

$$\text{Tangential component: } e_t = \frac{v_{2,t}}{v_{1,t}}$$



Particle fates

- “Escaped” trajectories are those that terminate at a flow boundary for which the “escape” condition is set.
- “Incomplete” trajectories are those that were terminated when the maximum allowed number of time steps was exceeded.
- “Trapped” trajectories are those that terminate at a flow boundary where the “trap” condition has been set.
- “Evaporated” trajectories include those trajectories along which the particles were evaporated within the domain.
- “Aborted” trajectories are those that fail to complete due to numerical/round-off reasons. If there are many aborted particles, try to redo the calculation with a modified length scale and/or different initial conditions.

Turbulent dispersion of particles

- Dispersion of particles due to turbulent fluctuations in the flow can be modeled using either:
 - Stochastic tracking (discrete random walk).
 - Particle cloud model.
- Turbulent dispersion is important because:
 - Physically more realistic (at an added computational expense).
 - Enhances stability by smoothing source terms and eliminating local spikes in coupling to the gas phase.

Turbulence: discrete random walk tracking

- Each injection is tracked repeatedly in order to generate a statistically meaningful sampling.
- Mass flow rates and exchange source terms for each injection are divided equally among the multiple stochastic tracks.
- Turbulent fluctuations in the flow field are represented by defining an instantaneous fluid velocity:


$$u_i = \overline{u_i} + u'_i$$

- where u'_i is derived from the local turbulence parameters:


$$u'_i = \zeta \sqrt{\frac{2k}{3}}$$

- and ζ is a normally distributed random number.

Stochastic tracking example - paper plane




- Stochastic tracking turned off.
- One track per injection point.
- Uses steady state velocities only and ignores effect of turbulence.



- Stochastic tracking turned on.
- Five tracks per injection point.
- Adds random turbulent dispersion to each track.
- Tracks that start in the same point are all different.

Turbulence: cloud tracking

- Uses statistical methods to trace the turbulent dispersion of particles about a mean trajectory.
- Calculate mean trajectory from the ensemble average of the equations of motion for the particles represented in the cloud.
- Distribution of particles inside the cloud is represented by a Gaussian probability density function.



Stochastic vs. cloud tracking

- Stochastic tracking:



- Accounts for local variations in flow properties.
- Requires a large number of stochastic tries in order to achieve a statistically significant sampling (function of grid density).
- Insufficient number of stochastic tries results in convergence problems due to non-smooth particle source term distributions.
- Recommended for use in complex geometry.




- Cloud tracking:



- Local variations in flow properties get averaged inside the particle cloud.
- Smooth distributions of particle coupling source terms.
- Each diameter size requires its own cloud trajectory calculation.

Injection set-up

- Injections may be defined as:
 - Single: a particle stream is injected from a single point.
 - Group: particle streams are injected along a line.
 - Cone: (3-D) particle streams are injected in a conical pattern.
 - Surface: particle streams are injected from a surface (one from each face).
 - File: particle streams injection locations and initial conditions are read in from an external file.



Injection definition

- Every injection definition includes:
 - Particle type (inert, droplet, or combusting particle).
 - Material (from data base).
 - Initial conditions (except when read from a file).
- Combusting particles and droplets require definition of destination species.
- Combusting particles may include an evaporating material.
- Turbulent dispersion may be modeled by stochastic tracking.

Solution strategy: particle tracking


- Cell should be crossed in a minimum of two or three particle steps. More is better.
- Adjust step length to either a small size, or 20 or more steps per cell.
- Adjust “Maximum Number of Steps.”
- Take care for recirculation zones.
- Heat and mass transfer: reduce the step length if particle temperature wildly fluctuates at high vaporization heats.

Solution strategy: coupled calculation

- Two strategies possible:
 - Closer coupling between dispersed and continuous flow:
 - Increase underrelaxation for discrete phase.
 - Decrease number of continuous phase calculations between trajectory calculations to less than three.
 - Reduce underrelaxation factors for continuous phase.
 - Decoupling of dispersed and continuous flow:
 - Reduce underrelaxation factor for discrete phase.
 - Increase number of continuous phase calculations between trajectory calculations to more than fifteen.
- Smooth out particle source terms.
 - Increase number of particle trajectories.


Particle tracking in unsteady flows

- Each particle advanced in time along with the flow.
- For coupled flows using implicit time stepping, sub-iterations for the particle tracking are performed within each time step.
- For non-coupled flows or coupled flows with explicit time stepping, particles are advanced at the end of each time step.





Sample planes and particle histograms

- Track mean particle trajectory as particles pass through sample planes (lines in 2D), properties (position, velocity, etc.) are written to files.
- These files can then be read into the histogram plotting tool to plot histograms of residence time and distributions of particle properties.
- The particle property mean and standard deviation are also reported.









Poincaré plots

- Poincaré plots are made by placing a dot on a given surface every time a particle trajectory hits or crosses that surface.
- Here it is shown for a flow inside a closed cavity with tangentially oscillating walls.
- The figure on the left shows streamlines.
- The figure on the right shows a Poincaré plot for the top surface.
- This method can be used to visualize flow structures.



Leapfrogging vortex rings

- Two ideal coaxial vortex rings with the same sense of rotation will leapfrog each other.
- The forward vortex increases in diameter and slows down. The rearward vortex shrinks and speeds up.
- Once the vortices traded places, the process repeats.
- The photographs on the left are experimental visualizations using smoke rings, and the figures on the right are Poincaré plots from a CFD simulation showing the same structures.




Aref and Naschie. Chaos applied to fluid mixing. Page 33 187. 1995.

Massive particle tracking


- Massive particle tracking refers to analyses where tens of thousands to millions of particles are tracked to visualize flows or to derive statistics of the flow field.
- Two examples:
 - A mixing tank with three impellers.
 - A mixing tank with four impellers.
 - Both animations show the motion of more than 29k particles.
 - It can be seen that one large flow loop forms in the three impeller system, and two flow loops form in the four impeller system.

Three impellers



Animation courtesy of Lightnin Inc.


Four impellers




Animation courtesy of Lightnin Inc.

Mixing vessel - velocity vectors

- Smaller diameter impeller (40% of vessel diameter).
- Impeller jet extends to the vessel bottom.




- Larger diameter impeller (50% of vessel diameter).
- Impeller jet bends off to the wall and the flow direction at the bottom is reversed.




Mixing vessel - tracking of sand particles

- Smaller diameter impeller.
- The sand is dispersed throughout the whole vessel with a small dead spot in the center of the bottom.



- Larger diameter impeller.
- Due to the reversed flow pattern at the bottom, sand does not get suspended throughout the whole vessel.




Kenics static mixer


- A static mixer is a device in which fluids are mixed, but has no moving parts.
- The mixing elements induce a flow pattern that results in the material being stretched and folded to form ever smaller structures.
- Mixing can be analyzed by looking at species concentration or by looking at particle paths.
- CPU time:
 - 1992. 100,000 cells. Sun Sparc II workstation. One week.
 - 1993. 350,000 cells. Cray C90 supercomputer. Overnight.
 - 2001. 350,000 cells. Two processor Unix workstation. 30 minutes.
 - 2001. Two-million cells. Two processor Unix workstation. Five hours.

Lattice-Boltzmann Method

- Calculations by Jos Derksen, Delft University, 2003.
- Unbaffled stirred tank equipped with a Rushton turbine.





Cross Section




Vessel Wall

Lattice-Boltzmann Method

- Calculations by Jos Derksen, Delft University, 2003.
- Unbaffled stirred tank equipped with four impellers.





Mixing mechanism




- Laminar mixing.
- CFD simulation.
- Six elements.
- Each element splits, stretches and folds the fluid parcels.
- Every two elements the fluid is moved inside-out.

Particle tracking animations



Species mixing animation



Question: are particle trajectories closed?

- Not in turbulent flows.
- Viscous, periodic flows may have periodic points. These are points where the particle returns to its initial position after a certain amount of time.
- Brouwer's fixed-point theorem:
Under a continuous mapping $f : S \rightarrow S$ of an n - dimensional simplex into itself there exists at least one point $x \in S$ such that $f(x) = x$.
- Application to particle tracks:
 - In viscous periodic flows in closed, simply connected domains there will always be at least one periodic point where a particle returned to its original location.
 - In other situations, there is no guarantee that there is any closed trajectory, and there may be none at all.

Question: how fast do particles separate?

- If we place two particles infinitesimally close together, will they stay together, or separate?
- The separation distance δ is governed by the Lyapunov exponent λ of the flow, which states that the particles will separate exponentially as a function of time t :

$$\delta(t) = \delta(0) e^{\lambda t}$$

- The higher the Lyapunov exponent, the more chaotic the flow and the more stretching occurs.
- Lyapunov exponents can have any value, most of the time between 0 and 10, and usually between 0.5 and 1.

Particle tracking accuracy

- There are three types of errors: discretization, time integration, and round-off.
- Research has shown that in regular laminar flows the error in the particle location increases as t^2 , and in chaotic flows almost exponentially.
- Errors tend to align with the direction of the streamlines in most flows.
- As a result, even though errors multiply rapidly (e.g. 0.1% error for 20,000 steps is $1.001^{20,000} = 4.8E8$), qualitative features of the flow as shown by the deformation of material lines can be properly reproduced. But the length of the material lines may be off by as much as 100%.
- Overall, particle tracking, when properly done, is less diffusive than solving for species transport, but numerical diffusion does exist.

Summary

- Easy-to-use model.
- Clear and simple physics.
- Restricted to volume fractions $< 10\%$.
- Particle tracking can be used for a variety of purposes:
 - Visualization.
 - Residence time calculations.
 - Combustion.
 - Chemical reaction.
 - Drying.
 - Particle formation processes.